



August 5, 2016

Brulin 815 GD and 815 QR-DF (10 gallons each or 12.5% concentration when mixed with water) may be used as an alternative to TierraTech Ultrasonic 7 and B solutions.

The Brulin ultrasonic solution volume concentration is based upon the MOT-500NS model (158.5 gallon capacity) ultrasonic cleaner. Adjust the solution rate to 238 ml (8.06 oz) of Brulin ultrasonic solution 815 GD to one gallon of water (3.785 l) and 238 ml (8.06 oz) of Brulin ultrasonic solution 815 QR-DF to one gallon of water (3.785 l) for ultrasonic cleaning units that have a different cleaning solution capacity.

Introduction of the alternative solutions would be done immediately prior to running a reference oil test, that is, the engine that is to run the reference oil would be cleaned by the alternative solutions.

Tim Cushing  
GM Global Propulsion Systems, Fluids and Lubricants